



Taper Lock® Bushes

Taper Lock Five Hole Bush

Simple, Universal Solution

3535 Imperial Bore

Screw Tightening Torque	Screw Quantity	Screw Size	Hex Socket Size	Large End Diameter	Bush Length	Approximate Mass
Nm		BSW	mm	mm	mm	Kg
115	3	1/2"	10	127	89	5

Fenner Reference	Bore Diameter	Keyway Width	Keyway Depth	Shallow Keyway Depth
	inch	inch	inch	inch
019R0108	1.5	0.375	0.11	-
019R0110	1.625	0.437	0.13	-
019R0112	1.75	0.437	0.13	-
019R0114	1.875	0.5	0.13	-
019R0200	2	0.5	0.13	-
019R0202	2.125	0.625	0.18	-
019R0204	2.25	0.625	0.18	-
019R0206	2.375	0.625	0.18	-
019R0208	2.5	0.625	0.18	-
019R0210	2.625	0.75	0.21	-
019R0212	2.75	0.75	0.21	-
019R0214	2.875	0.75	0.21	-
019R0300	3	0.75	0.21	-
019R0302	3.125	0.875	0.26	-
019R0304	3.25	0.875	0.26	-
019R0306	3.375	0.875	0.26	-
019R0308	3.5	0.875	0.26	-



All Keyways are parallel and to British Standard 46: Part 1: 1958, with the exception of those marked* which are shallower. Where a key is to be used it should be side fitting, with top clearance. Depth of keyway is measured at the CENTRE.

Fenner®

Reliable | Trusted | Connected