



# Taper Lock® Bushes

## Taper Lock Five Hole Bush

Simple, Universal Solution

### 4030 Imperial Bore

Screw Tightening Torque	Screw Quantity	Screw Size	Hex Socket Size	Large End Diameter	Bush Length	Approximate Mass
Nm		BSW	mm	mm	mm	Kg
170	3	5/8"	12	146	76.2	5.6

Fenner Reference	Bore Diameter	Keyway Width	Keyway Depth	Shallow Keyway Depth
	inch	inch	inch	inch
019X0112	1.75	0.437	0.13	–
019X0114	1.875	0.5	0.13	–
019X0200	2	0.5	0.13	–
019X0202	2.125	0.625	0.18	–
019X0204	2.25	0.625	0.18	–
019X0206	2.375	0.625	0.18	–
019X0208	2.5	0.625	0.18	–
019X0210	2.625	0.75	0.21	–
019X0212	2.75	0.75	0.21	–
019X0214	2.875	0.75	0.21	–
019X0300	3	0.75	0.21	–
019X0302	3.125	0.875	0.26	–
019X0304	3.25	0.875	0.26	–
019X0306	3.375	0.875	0.26	–
019X0308	3.5	0.875	0.26	–
019X0312	3.75	1	0.32	0.245
019X0400	4	1	0.32	0.155
<b>019X0404</b>	4.25	1.25	0.37	–
<b>019X0408*</b>	4.5	1.25	0.37	0.255



All Keyways are parallel and to British Standard 46: Part 1: 1958, with the exception of those marked\* which are shallower. Where a key is to be used it should be side fitting, with top clearance. Depth of keyway is measured at the CENTRE.

**Bold indicates bushes made of steel or ductile iron.**

# Fenner®

Reliable | Trusted | Connected